



UNIVERSE CONSTANT

USER MANUAL



CONTENTS

INTRODUCTION	_____	5
INTERNATIONAL WARRANTY	_____	6
WINDING THE WATCH	_____	8
SETTING THE TIME	_____	11
SETTING THE DATE	_____	14

Master of Time



UNIVERSE CONSTANT

INTRODUCTION



INTRODUCTION

Time is the sum of unique moments.

And living each of these moments fully, managing time skillfully, is an art.

What truly makes time valuable is how we perceive it, our approach to it.

Crafted with mastery,

UNIVERSE CONSTANT reigns over time, reminding us of the power we hold to add significant value, granting us the courage to perfect each moment.

UNIVERSE CONSTANT is indispensable for those who truly value time.



INTERNATIONAL WARRANTY

Universe Constant watches are the product of our Manufacture and are high-precision, high-tech products. Before your watch leaves the Manufacture, it is subjected to numerous stringent quality checks. However, should there be any manufacturing faults, an international guarantee means your watch is covered for two years starting from the date of purchase. This guarantee is observed by service centres approved by Universe Constant worldwide if the following cumulative conditions are observed:


- The watch has been purchased from an official dealer as approved by Universe Constant; you can find the list of all authorised point of sales on our website, universeconstant.com. The name or stamp of the authorised retailers, the date of purchase and the watch reference are clearly detailed on the guarantee card.
- Your watch must have been worn under normal conditions and maintained in accordance with Universe Constant's recommended maintenance instructions; it must not have been handled incorrectly.
- The guarantee card, the only valid proof of purchase, must be sent along with your watch to an authorised Universe Constant service centre.

WINDING THE WATCH



WINDING THE WATCH

Your watch is fitted with an automatic winding mechanical movement. The movement is wound via the crown or the effect of the oscillating weight. When the watch is worn, the motion of the wrist activates the oscillating weight to wind the movement. In order for the automatic winding to work properly, the watch must be worn for at least 12 hours per day, for several days.






WHEN YOUR WATCH HAS STOPPED

Not wearing the watch enough causes it to stop. Hold the watch in your hand and turn the crown at least 30 times clockwise. The barrel that contains the mainspring has now been wound. If you do not wear your watch during the night, turn the crown a few times the following morning before you put it on.

Note: for models equipped with a screw-down crown, unscrew the crown before winding the watch. Screw in the crown after the operation.





SETTING THE TIME



SETTING THE TIME

Tip: it is easier to set the time while holding the watch rather than wearing it. We recommend gentle, regular turns when rotating the crown.


Important for models with a date display:

- Always set the time in a clockwise direction to avoid damaging the movement.
- Start by performing one complete rotation to 12 o'clock to check the part of the day for which you are setting the time: if the date changes when the hand passes 12 o'clock, your watch is showing the morning time. If the date does not change, your watch is showing the afternoon time.



SETTING THE TIME

Pull the crown out to position (2). Rotate the hands clockwise to indicate the desired time. At the time signal, push the crown back against the case.




SETTING THE DATE



SETTING THE DATE

Pull the crown out to position (1). Rotate the crown until the desired date appears. Once the date has been set, you can set the time. Push the crown back against the case.





UNIVERSE CONSTANT

Master of Time

universeconstant.com